

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.6	16.4	GC-18-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.5	16.4	GC-72-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.6	16.4	GC-18-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.6	16.6	GC-24-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.7	17.5	GC-60-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.7	17.5	GC-60-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.7	17.8	GC-24-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.7	18.3	GC-47-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.7	18.3	GC-47-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	17.9	GC-54-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	17.9	GC-54-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	18.1	GC-30-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	18.1	GC-30-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	18.9	GC-42-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	18.9	GC-42-****-WH
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	19.5	GC-38-****-NW
Advanced Geothermal Technology	Advanced Geothermal Technology	Great Air Comfort System	DGX	3.8	19.5	GC-38-****-WH
Bard Manufacturing Company, Inc.	Bard Manufacturing, Inc.	GeoTec	Closed Loop with integrated WH	3.6-4.8	15.0-26.2	Any model starting with GV in sizes 27 to 71
Bard Manufacturing Company, Inc.	Bard Manufacturing, Inc.	GeoTec	Open Loop with integrated WH	4.2-5.4	18.7-30.6	Any model starting with GV in sizes 27 to 71
Bard Manufacturing Company, Inc.	Bard Manufacturing, Inc.	GSVS Series	Closed Loop with integrated WH	3.4-4.0	15.0-18.0	Any model starting with GSVS in sizes 242-601
Bard Manufacturing Company, Inc.	Bard Manufacturing, Inc.	GSVS Series	Open Loop with integrated WH	3.6-4.1	18.5-22.0	Any model starting with GSVS in sizes 242-601
Bard Manufacturing Company, Inc.	Bard Manufacturing, Inc.	Q-Tec	Closed Loop with integrated WH	3.3-3.5	16.1-16.5	Any model starting with QW in sizes 30-42
Bard Manufacturing Company, Inc.	Bard Manufacturing, Inc.	Q-Tec	Open Loop with integrated WH	3.6-4.3	19.5-23.0	Any model starting with QW in sizes 24-48
Corporation)	Bryant	GT-G	Closed Loop	3.4-3.8	14.6-18.5	Any model starting with 50YC (V/H/D) in sizes 015 to 060
Corporation)	Bryant	GT-G	Open Loop	3.6-4.1	16.8-23.9	Any model starting with 50YC (V/H/D) in sizes 015 to 070
Corporation)	Bryant	GT-GS	Closed Loop	3.3-3.6	14.2-16.6	Any model starting with 50YCS in sizes 018 to 060
Corporation)	Bryant	GT-GS	Open Loop	3.7-4.0	17.2-22.1	Any model starting with 50YCS in sizes 018 to 060
Corporation)	Bryant	GT-PE	Closed Loop	4.0	20.2	Any model starting with 50YPS038
Corporation)	Bryant	GT-PE	Closed Loop	4.0	21.3	Any model starting with 50YPS026
Corporation)	Bryant	GT-PE	Closed Loop	4.1	18.8	Any model starting with 50YPS064
Corporation)	Bryant	GT-PE	Closed Loop	4.1	19.7	Any model starting with 50YPS049
Corporation)	Bryant	GT-PE	Open Loop	4.4	22.5	Any model starting with 50YPS064
Corporation)	Bryant	GT-PE	Open Loop	4.6	23.9	Any model starting with 50YPS049
Corporation)	Bryant	GT-PE	Open Loop	4.6	24.3	Any model starting with 50YPS038
Corporation)	Bryant	GT-PE	Open Loop	4.7	26.3	Any model starting with 50YPS026
Corporation)	Bryant	GT-PG	Closed Loop	3.6-4.2	16.6-20.2	Any model starting with 50YE in sizes 018 to 070
Corporation)	Bryant	GT-PG	Open Loop	4.3-5.1	21.6-28.1	Any model starting with 50YE in sizes 018 to 070
Corporation)	Bryant	GT-PX	Closed Loop	3.6-4.6	15.3-27.0	Any model starting with 50YD in sizes 026 to 072
Corporation)	Bryant	GT-PX	Open Loop	4.3-5.1	19.2-31.5	Any model starting with 50YD in sizes 026 to 072
Corporation)	Bryant	GT-S	Closed Loop	3.3-3.6	14.2-16.6	Any model starting with 38WQS in sizes 018 to 060
Corporation)	Bryant	GT-S	Open Loop	3.7-4.0	17.2-22.1	Any model starting with 38WQS in sizes 018 to 060
Carrier Corporation	Carrier	50vs Series	Closed Loop	3.9	19.5	VHC4
Carrier Corporation	Carrier	50vs Series	Closed Loop	3.9	20.0	VHC3
Carrier Corporation	Carrier	50vs Series	Closed Loop	4.0	19.0	VHC6
Carrier Corporation	Carrier	50vs Series	Closed Loop	4.0	19.0	VHC7
Carrier Corporation	Carrier	50vs Series	Closed Loop	4.0	21.0	VHC2
Carrier Corporation	Carrier	50vs Series	Closed Loop	4.1	21.0	VHC1
Carrier Corporation	Carrier	50vs Series	Closed Loop	4.2	20.0	VHC5
Carrier Corporation	Carrier	50vs Series	Open Loop	3.9	19.5	VHC4
Carrier Corporation	Carrier	50vs Series	Open Loop	3.9	20.0	VHC3
Carrier Corporation	Carrier	50vs Series	Open Loop	4.0	19.0	VHC6
Carrier Corporation	Carrier	50vs Series	Open Loop	4.0	19.0	VHC7
Carrier Corporation	Carrier	50vs Series	Open Loop	4.0	21.0	VHC2
Carrier Corporation	Carrier	50vs Series	Open Loop	4.1	21.0	VHC1
Carrier Corporation	Carrier	50vs Series	Open Loop	4.2	20.0	VHC5
Carrier Corporation	Carrier	AQUAZONE	Closed Loop	3.6	17.8	ECM blower
Carrier Corporation	Carrier	AQUAZONE	Closed Loop	3.8	14.6	Any model starting with 50R(V/D/H/S) in sizes 015 to 060
Carrier Corporation	Carrier	AQUAZONE	Closed Loop	4.3	25.3	Any model starting with 50PT in sizes 026 to 064
Carrier Corporation	Carrier	AQUAZONE	Open Loop	3.8	16.8	Any model starting with 50R(V/D/H/S) in sizes 015 to 070
Carrier Corporation	Carrier	AQUAZONE	Open Loop	4.3	21.6	ECM blower
Carrier Corporation	Carrier	AQUAZONE	Open Loop	4.4	23.5	ECM blower
Carrier Corporation	Carrier	AQUAZONE	Open Loop	4.7	29.7	Any model starting with 50PT in sizes 026 to 064
Carrier Corporation	Carrier	GT-G	Closed Loop	3.4-3.8	14.6-18.5	Any model starting with 50YC(V/H/D) in sizes 015 to 060
Carrier Corporation	Carrier	GT-G	Open Loop	3.6-4.1	16.8-23.9	Any model starting with 50YC(V/H/D) in sizes 015 to 070
Carrier Corporation	Carrier	GT-GS	Closed Loop	3.3-3.6	14.2-16.6	Any model starting with 50YCS in sizes 018 to 060
Carrier Corporation	Carrier	GT-GS	Open Loop	3.7-4.0	17.2-22.1	Any model starting with 50YCS in sizes 018 to 060
Carrier Corporation	Carrier	GT-PE	Closed Loop	4.0	20.2	Any model starting with 50YPS038
Carrier Corporation	Carrier	GT-PE	Closed Loop	4.0	21.3	Any model starting with 50YPS026
Carrier Corporation	Carrier	GT-PE	Closed Loop	4.1	18.8	Any model starting with 50YPS064
Carrier Corporation	Carrier	GT-PE	Closed Loop	4.1	19.7	Any model starting with 50YPS049
Carrier Corporation	Carrier	GT-PE	Open Loop	4.4	22.5	Any model starting with 50YPS064
Carrier Corporation	Carrier	GT-PE	Open Loop	4.6	23.9	Any model starting with 50YPS049
Carrier Corporation	Carrier	GT-PE	Open Loop	4.6	24.3	Any model starting with 50YPS038
Carrier Corporation	Carrier	GT-PE	Open Loop	4.7	26.3	Any model starting with 50YPS026
Carrier Corporation	Carrier	GT-PG	Closed Loop	3.6-4.2	16.6-20.2	Any model starting with 50YE in sizes 018 to 070
Carrier Corporation	Carrier	GT-PG	Open Loop	4.3-5.1	21.6-28.1	Any model starting with 50YE in sizes 018 to 070
Carrier Corporation	Carrier	GT-PX	Closed Loop	3.6-4.6	15.3-27.0	Any model starting with 50YD in sizes 026 to 072
Carrier Corporation	Carrier	GT-PX	Open Loop	4.3-5.1	19.2-31.5	Any model starting with 50YD in sizes 026 to 072
Carrier Corporation	Carrier	GT-S	Closed Loop	3.3-3.6	14.2-16.6	Any model starting with 38WQS in sizes 018 to 060
Carrier Corporation	Carrier	GT-S	Open Loop	3.7-4.0	17.2-22.1	Any model starting with 38WQS in sizes 018 to 060
ClimateMaster Inc.	ClimateMaster	Genesis	Closed Loop	3.3-3.5	14.2-15.0	All models starting with GR except sizes 19, 24, and 60
ClimateMaster Inc.	ClimateMaster	Genesis	Closed Loop	3.8	18.5	GSV/GSH015
ClimateMaster Inc.	ClimateMaster	Genesis	Open Loop	3.6-4.1	16.8-18.6	All models starting with GR
ClimateMaster Inc.	ClimateMaster	Genesis	Open Loop	4.10	23.90	GSV/GSH015
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.3	16.7	TSV012; TSH012
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.30	17.50	TSV009; TSH009
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.40	18.10	TSV006; TSH006
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.6	15.3	TTSD064
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.6	16.2	TTV072; TTD072; TSH072
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.6	16.6	Any model starting with TSV070; TSD070; TSH070
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.6-4.15	18.4-21.4	All models beginning with TTP
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.7	17.6	Any model starting with TSV048; TSD048; TSH048
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.7	18.2	Any model starting with TSV060; TSD060; TSH060
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.7	19.0	Any model starting with TSV018; TSD018; TSH018
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.7	19.1	Any model starting with TSV024; TSD024; TSH024
ClimateMaster Inc.	ClimateMaster	Tranquility	Closed Loop	3.8	16.7	TTSD038

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	3.8	17.6	Any model starting with TSV030; TSD030; TSH030
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	3.8	18.4	Any model starting with TSV042; TSD042; TSH042
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	3.9	18.0	TTSO26
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	3.9	19.2	Any model starting with TSV036; TSD036; TSH036
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	4.0	16.6	TTSO49
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	4.1	21.4	Any model starting with TTV049; TTD049; TTH049
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	4.1	21.4	Any model starting with TTV064; TTD064; TTH064
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	4.25	22.6	Any model starting with TTV038; TTD038; TTH038
ClimateMaster Inc.	Climatemaster	Tranquility	Closed Loop	4.3	22.25	Any model starting with TTV026; TTD026; TTH026
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	3.9	22.0	TSV012; TSH012
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	3.95-4.65	22.35-26.3	All models beginning with TTP
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.1	24.0	TSV009; TSH009
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.3	19.2	TTSO64
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.3	19.9	TTV072; TTD072; TSH072
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.3	24.7	TSV006; TSH006
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.3	25.7	Any model starting with TSV024; TSD024; TSH024
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.4	22.9	Any model starting with TSV030; TSD030; TSH030
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.4	23.3	Any model starting with TSV048; TSD048; TSH048
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.5	21.4	TTSO38
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.5	23.2	Any model starting with TSV060; TSD060; TSH060
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.55	25.85	Any model starting with TTV064; TTD064; TTH064
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.6	20.9	TTSO49
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.6	24.3	Any model starting with TSV042; TSD042; TSH042
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.6	26.7	Any model starting with TSV018; TSD018; TSH018
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.7	23.2	TTSO26
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.8	25.1	Any model starting with TSV036; TSD036; TSH036
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.9	25.6	Any model starting with TTV049; TTD049; TTH049
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.9	27.25	Any model starting with TTV038; TTD038; TTH038
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.95	27.65	Any model starting with TTV026; TTD026; TTH026
ClimateMaster Inc.	Climatemaster	Tranquility	Open Loop	4.3	21.6	Any model starting with TSV070; TSD070; TSH070
ClimateMaster Inc.	Genesis	Genesis	Closed Loop	3.3 - 3.6	14.2 - 16.6	all GSS series
ClimateMaster Inc.	Genesis	Genesis	Closed Loop	3.5 - 3.8	14.6 - 17.5	all GSV/GSH and having
ClimateMaster Inc.	Genesis	Genesis	Closed Loop	3.8 - 4.1	14.6 - 18.5	GSV/GSH018; GSV/GSH024; GSV/GSH030; GSV/GSH036
ClimateMaster Inc.	Genesis	Genesis	Closed Loop	3.8 - 4.1	14.6 - 18.5	; GSV/GSH042; GSV/GSH048; GSV/GSH060
ClimateMaster Inc.	Genesis	Genesis	Open Loop	3.8 - 4.1	17.1 - 21.5	all GSV/GSH and having
ClimateMaster Inc.	Genesis	Genesis	Open Loop	3.8 - 4.1	16.8 - 23.9	all GSV/GSH series
ClimateMaster Inc.	Paradigm	Paradigm	Closed Loop	3.3 - 3.6	14.2 - 16.6	all PDW series
ClimateMaster Inc.	VT	VT	Closed Loop	3.35 - 4.25	15.4 - 18.65	all VT series
Eagle Mountain	Geomax	Denali	Closed Loop	3.6	16.6	Any model starting with VXVO18
Eagle Mountain	Geomax	Denali	Closed Loop	3.8	17.0	Any model starting with VXVO15
Eagle Mountain	Geomax	Denali	Open Loop	4.7	23.0	Any model starting with VXVO18
Eagle Mountain	Geomax	Denali	Open Loop	4.7	24.0	Any model starting with VXVO15
Eagle Mountain	Geomax	Everest	Closed Loop	3.6	16.5	Any model starting with GT72
Eagle Mountain	Geomax	Everest	Closed Loop	3.7	17.9	Any model starting with GS70
Eagle Mountain	Geomax	Everest	Closed Loop	3.8	19.2	Any model starting with GS60
Eagle Mountain	Geomax	Everest	Closed Loop	3.9	17.5	Any model starting with GT49
Eagle Mountain	Geomax	Everest	Closed Loop	3.9	17.5	Any model starting with GT64
Eagle Mountain	Geomax	Everest	Closed Loop	3.9	21.2	Any model starting with GS30
Eagle Mountain	Geomax	Everest	Closed Loop	4.0	19.5	Any model starting with GS48
Eagle Mountain	Geomax	Everest	Closed Loop	4.0	22.0	Any model starting with GS22
Eagle Mountain	Geomax	Everest	Closed Loop	4.1	19.0	Any model starting with GT26
Eagle Mountain	Geomax	Everest	Closed Loop	4.1	22.2	Any model starting with GS42
Eagle Mountain	Geomax	Everest	Closed Loop	4.2	19.8	Any model starting with GT38
Eagle Mountain	Geomax	Everest	Closed Loop	4.2	21.8	Any model starting with GS36
Eagle Mountain	Geomax	Everest	Open Loop	4.4	22.2	Any model starting with GT64
Eagle Mountain	Geomax	Everest	Open Loop	4.5	21.6	Any model starting with GT72
Eagle Mountain	Geomax	Everest	Open Loop	4.5	24.3	Any model starting with GS70
Eagle Mountain	Geomax	Everest	Open Loop	4.6	25.5	Any model starting with GS60
Eagle Mountain	Geomax	Everest	Open Loop	4.7	22.7	Any model starting with GT49
Eagle Mountain	Geomax	Everest	Open Loop	4.9	24.1	Any model starting with GT38
Eagle Mountain	Geomax	Everest	Open Loop	4.9	27.0	Any model starting with GS48
Eagle Mountain	Geomax	Everest	Open Loop	5.1	25.8	Any model starting with GT26
Eagle Mountain	Geomax	Everest	Open Loop	5.1	29.5	Any model starting with GS42
Eagle Mountain	Geomax	Everest	Open Loop	5.1	30.0	Any model starting with GS30
Eagle Mountain	Geomax	Everest	Open Loop	5.2	29.8	Any model starting with GS36
Eagle Mountain	Geomax	Everest	Open Loop	5.4	32.2	Any model starting with GS22
Eagle Mountain	Geomax	Rainier	Closed Loop	3.4	15.1	Any model starting with QT64
Eagle Mountain	Geomax	Rainier	Closed Loop	3.6	14.7	Any model starting with QT72
Eagle Mountain	Geomax	Rainier	Closed Loop	3.6	16.3	Any model starting with QT49
Eagle Mountain	Geomax	Rainier	Closed Loop	3.9	18.2	Any model starting with QT38
Eagle Mountain	Geomax	Rainier	Open Loop	4.0	17.4	Any model starting with QT72
Eagle Mountain	Geomax	Rainier	Open Loop	4.0	18.5	Any model starting with QT64
Eagle Mountain	Geomax	Rainier	Open Loop	4.4	21.7	Any model starting with QT49
Eagle Mountain	Geomax	Rainier	Open Loop	4.5	19.3	Any model starting with QT38
Eagle Mountain	Geomax	Sierra	Closed Loop	3.3	14.7	Any model starting with PO66
Eagle Mountain	Geomax	Sierra	Closed Loop	3.5	16.1	Any model starting with PO56
Eagle Mountain	Geomax	Sierra	Closed Loop	3.5	16.6	Any model starting with PO13
Eagle Mountain	Geomax	Sierra	Closed Loop	3.6	16.4	Any model starting with PO46
Eagle Mountain	Geomax	Sierra	Closed Loop	3.7	16.9	Any model starting with PO19
Eagle Mountain	Geomax	Sierra	Closed Loop	3.7	16.9	Any model starting with PO34
Eagle Mountain	Geomax	Sierra	Closed Loop	3.7	17.4	Any model starting with PO10
Eagle Mountain	Geomax	Sierra	Closed Loop	3.7	18.0	Any model starting with PO40
Eagle Mountain	Geomax	Sierra	Closed Loop	3.8	16.9	Any model starting with PO28
Eagle Mountain	Geomax	Sierra	Closed Loop	3.8	18.9	Any model starting with PO22
Eagle Mountain	Geomax	Sierra	Open Loop	4.9	16.7	Any model starting with PO40
Eagle Mountain	Geomax	Sierra	Open Loop	5.0	16.7	Any model starting with PO22
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.7	15.9	SC-024-1
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.7-4.0	15.9-17.3	SC Series
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.7-4.0	15.9-17.3	SW Series
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with CWH
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with HC
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with HCW
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with HW
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with HWW
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with SC
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with SCW

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with 5D
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with SW
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	15.9	All models beginning with SWW
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.8	17.7	SC-030-1
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.9	17.1	SC-036-1
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.9	17.1	SC-048-1
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	3.9	17.3	SC-060-1
EarthLinked Technologies, Inc.	EarthlinkedTM	EarthlinkedTM	DGX	4.0	16.8	SC-042-1
Earth To Air Systems, LLC	Earth To Air Systems	TSDX	DGX	3.9	21	TS18,24,27,30,36,42,48,54,60
Efficiency Power	Freus Geothermal	FreusGeo	DGX	N/A	17.35	FG42
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Single Capacity	Closed Loop	3.4	14.8	Any model starting with GC in sizes 018 to 060
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Single Capacity	Open Loop	3.9	17.1	Any model starting with GC sizes 018 to 060
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Series, Single Capacity-Split	Closed Loop	3.3	15.4	Any model starting with GSC in sizes 018 to 060
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Single Capacity-Split	Open Loop	3.7	17.5	Any model starting with GSC in sizes 018 to 072
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Single Capacity	Closed Loop	3.4	16.0	Any model starting with GS in sizes 018 to 072
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Single Capacity	Open Loop	3.9	18.4	Any model starting with GS in sizes 018 to 072
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Series, Dual Capacity-Split	Closed Loop	3.3	15.1	Any model starting with GTC in sizes 024, 036, 048, 060
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Series, Dual Capacity-Split	Open Loop	3.8	17.4	Any model starting with GTC in sizes 024, 036, 048, 060
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Dual Capacity	Closed Loop	3.5	14.1	072, 096, 120
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Dual Capacity	Open Loop	4.1	16.2	072, 096, 120
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Closed Loop	3.4	14.8	48, 54, 60
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Open Loop	3.4	14.8	48, 54, 60
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Closed Loop	3.5	14.1	073, 096, 120
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Open Loop	4.1	16.2	073, 096, 120
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity-Split	Closed Loop	3.5	15.1	062C
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity-Split	Open Loop	4.0	17.4	062C
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Closed Loop	3.4	16.0	042, 048, 060, 072
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Open Loop	3.4	16.0	042, 048, 060, 072
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity-Split	Closed Loop	3.3	15.4	036C, 042C, 048C, 060C
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity-Split	Open Loop	3.7	17.5	048C, 060C, 072C
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Closed Loop	3.5	16.0	Any model starting with TVT in sizes 028, 040, 054, 066
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Open Loop	4.0	18.4	Any model starting with TVT in sizes 028, 040, 054, 066
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Closed Loop	3.3	15.1	Any model starting with TST in sizes 028, 040, 054, 066
Enertech Manufacturing, LLC	Enertech Manufacturing, LLC	Capacity	Open Loop	3.8	17.4	Any model starting with TST in sizes 028, 040, 054, 066
Enertech Manufacturing, LLC	GeoComfort	Compass	Closed Loop	3.8	17.6	GXT060A
Enertech Manufacturing, LLC	GeoComfort	Compass	Closed Loop	3.9	15.6	GXT072A
Enertech Manufacturing, LLC	GeoComfort	Compass	Closed Loop	4.0	17.7	GXT048A
Enertech Manufacturing, LLC	GeoComfort	Compass	Closed Loop	4.1	18.2	GXT036A
Enertech Manufacturing, LLC	GeoComfort	Compass	Open Loop	4.4	18.3	GXT072A
Enertech Manufacturing, LLC	GeoComfort	Compass	Open Loop	4.5	20.9	GXT060A
Enertech Manufacturing, LLC	GeoComfort	Compass	Open Loop	4.5	22.0	GXT036A
Enertech Manufacturing, LLC	GeoComfort	Compass	Open Loop	4.6	21.7	GXT048A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Closed Loop	3.8	17.6	HXT060A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Closed Loop	3.9	15.6	HXT072A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Closed Loop	4.0	17.7	HXT048A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Closed Loop	4.1	18.2	HXT036A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Open Loop	4.4	18.3	HXT072A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Open Loop	4.5	20.9	HXT060A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Open Loop	4.5	22.0	HXT036A
Enertech Manufacturing, LLC	Hydron Module	Revolution	Open Loop	4.6	21.7	HXT048A
Enertech Manufacturing, LLC	Roth	TerraStar	Closed Loop	3.8	17.6	RXT060A
Enertech Manufacturing, LLC	Roth	TerraStar	Closed Loop	3.9	15.6	RXT072A
Enertech Manufacturing, LLC	Roth	TerraStar	Closed Loop	4.0	17.7	RXT048A
Enertech Manufacturing, LLC	Roth	TerraStar	Closed Loop	4.1	18.2	RXT036A
Enertech Manufacturing, LLC	Roth	TerraStar	Open Loop	4.4	18.3	RXT072A
Enertech Manufacturing, LLC	Roth	TerraStar	Open Loop	4.5	20.9	RXT060A
Enertech Manufacturing, LLC	Roth	TerraStar	Open Loop	4.5	22.0	RXT036A
Enertech Manufacturing, LLC	Roth	TerraStar	Open Loop	4.6	21.7	RXT048A
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Closed Loop	3.3	14.2-16.0	CA Series Models 009, 012, 015
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Closed Loop	3.3-3.4	14.1-15.3	070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Closed Loop	3.3-3.6	14.1-15.8	EC Series Models CF, HZ, VT, 015, 018, 024
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Closed Loop	3.3-3.6	14.1-15.8	060, 061, 070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Closed Loop	3.6-4.0	15.5-24.5	All AU Series Models CF, HZ, VT, CS
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Open Loop	3.6-3.8	19.4-22.3	CA Series Models 009, 012, 015
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Open Loop	3.6-4.2	16.4-20.6	024
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Open Loop	3.6-4.2	16.4-20.6	060, 061, 070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Open Loop	3.7-4.1	17.9-20.2	070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius	Open Loop	4.0-4.6	19.0-30.0	All AU Series Models CF, HZ, VT, CS
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius 2	Closed Loop	4.1-4.8	18.0-28.5	All AP Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Aquarius 2	Open Loop	4.6-5.5	21.8-34.0	All AP Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Energy Miser	Closed Loop	3.3-3.5	14.4-15.5	EM Series Models CF, HZ, VT, 024, 028, 036, 051, 061
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Energy Miser	Open Loop	3.7-4.2	16.2-21.0	EM Series Models CF, HZ, VT, 007, 009, 018, 024, 028
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Energy Miser	Open Loop	3.7-4.2	16.2-21.0	051, 060, 061, 070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroMiser	Closed Loop	3.3	14.7-17.6	EV Series Models CS 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroMiser	Closed Loop	3.3-3.4	15.0-18.5	All EV Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroMiser	Open Loop	3.6-4.2	18.8-23.5	EV Series Models CS 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroMiser	Open Loop	3.6-4.3	19.2-25.4	All EV Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroSaver	Closed Loop	3.3-3.7	14.7-19.7	ES Series Models CS 018, 024, 025, 030, 035, 036
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroSaver	Closed Loop	3.3-3.7	14.7-19.7	ES Series Models CS 042, 048, 049, 060, 061, 070, 071
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroSaver	Closed Loop	3.3-4.0	15.5-24.5	All ES Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroSaver	Open Loop	3.6-4.5	18.6-25.4	ES Series Models CS 018, 024, 025, 030, 035, 036
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroSaver	Open Loop	3.6-4.5	18.6-25.4	ES Series Models CS 042, 048, 049, 060, 061, 070, 071
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	EnviroSaver	Open Loop	3.9-4.6	19.0-30.0	All ES Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Geo Saver	Closed Loop	3.3-4.1	14.3-20.7	All GS Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Geo Saver	Open Loop	3.9-4.9	18.3-25.9	All GS Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Geo Thermal	Closed Loop	3.3-4.0	14.1-18.5	All GT Series Models CF, HZ, VT
FHP Manufacturing Bosch Group	FHP Manufacturing Co.	Geo Thermal	Open Loop	3.8-4.7	17.5-24.0	All GT Series Models CF, HZ, VT
Free Source Energies LLC	Redwood Direct	RDX	DGX	3.63	16.6	All models beginning with RDX-360
Geofinity Manufacturing	Atlas	AT048	Closed Loop	4.3	18.6	AT048**D**.*E***
Geofinity Manufacturing	Atlas	AT048	Open Loop	4.7	21.4	AT048**D**.*E***
Geofinity Manufacturing	Zephyrus	ZP018	Closed Loop	4.0	19.4	ZP018**S**.*E***
Geofinity Manufacturing	Zephyrus	ZP018	Open Loop	5.1	28.3	ZP018**S**.*E***
Geofinity Manufacturing	Zephyrus	ZP036	Closed Loop	4.0	19.0	ZP036**D**.*E***
Geofinity Manufacturing	Zephyrus	ZP036	Open Loop	4.5	23.3	ZP036**D**.*E***
Geofinity Manufacturing	Zephyrus	ZP048	Closed Loop	4.5	20.8	ZP048**D**.*E***
Geofinity Manufacturing	Zephyrus	ZP048	Open Loop	5.0	25.0	ZP048**D**.*E***

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
Geofinity Manufacturing	Zephyrus	ZP060	Closed Loop	4.2	20.1	ZP060**D* - **E***
Geofinity Manufacturing	Zephyrus	ZP060	Open Loop	4.9	25.8	ZP060**D* - **E***
Geofinity Manufacturing	Zephyrus	ZP066	Closed Loop	4.2	18.1	ZP066**D* - **E***
Geofinity Manufacturing	Zephyrus	ZP066	Open Loop	4.7	22.0	ZP066**D* - **E***
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Closed Loop	3.50-3.92	14.90-17.53	MC024I, MC036I, MC048I, MC060I, MC072I
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Closed Loop	3.66-4.08	15.26-20.17	MC024T, MC036T, MC048T, MC060T
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Closed Loop	3.73-4.00	15.25-19.02	MA024I, MA036I, MA048I, MA060I, MA072I
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Closed Loop	3.84-4.09	15.74-20.30	MA024T, MA036T, MA048T, MA060T, MA072T
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Open Loop	4.06-4.40	16.86-20.27	MC024I, MC036I, MC048I, MC060I, MC072I
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Open Loop	4.07-4.33	17.24-20.29	MA024I, MA036I, MA048I, MA060I, MA072I
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Open Loop	4.18-4.42	15.50-22.11	MA024T, MA036T, MA048T, MA060T, MA072T
GeoFurnace Manufacturing, Inc	GeoFurnace	MTEX Series Water to Air	Open Loop	4.22-4.45	18.18-21.69	MC024T, MC036T, MC048T, MC060T
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.3	15.3	ES070-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.3	15.6	ES024-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.3	16.2	ES042-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.3	16.2	ES042-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.4	16.9	ES048-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.4	18.6	ES036-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.4	19.7	ES030-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.4	19.7	ES030-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.5	19.6	ES018-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.5	21.4	ES071-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.9	24.0	ES025-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Closed Loop	3.9	24.0	ES035-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	3.6	21.5	ES024-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	3.8	19.7	ES060-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	3.8	19.7	ES060-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	3.9	24.7	ES071-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.0	19.9	ES070-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.0	19.9	ES070-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.0	21.2	ES042-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.0	21.2	ES042-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.0	27.4	ES018-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.1	25.4	ES030-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.1	25.4	ES030-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.2	21.2	ES048-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.2	21.2	ES048-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.3	23.4	ES036-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.3	23.4	ES036-3CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.4	27.4	ES035-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.5	23.5	ES049-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.5	25.5	ES061-1CS
GeoMaster, LLC	GEOEXCEL	GEOEXCEL	Open Loop	4.5	29.4	ES024-3CS
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3	14.2-16.0	CA009, 012, 015
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3	14.7-17.6	EV Models CS 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3-3.4	14.1-15.3	EC Models CS 018, 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3-3.4	15.0-18.5	All EV Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3-3.5	14.4-15.5	EM Models VT, HZ, CF 024, 028, 036, 051, 061
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3-3.6	14.1-15.8	051, 060, 061, 070
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3-4.0	15.5-24.5	All ES Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.3-4.1	14.3-20.7	All GS Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.6-4.0	15.5-24.5	All AU Models VT, HZ, CF, CS
GeoMaster, LLC	GeoExcel	GeoExcel	Closed Loop	3.8-4.7	14.1-18.5	All GT Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.6-3.8	19.4-22.3	CA009, 012, 015
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.6-4.2	16.4-20.6	EC Models VT, HZ, CF 007, 009, 012, 015, 018
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.6-4.2	16.4-20.6	061, 070
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.6-4.2	18.8-23.5	EV Models CS 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.6-4.3	19.2-25.4	All EV Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.7-4.1	17.9-20.2	EC Models CS 018, 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.7-4.2	16.2-21.0	EM Models VT, HZ, CF 007, 009, 018, 024, 028, 031
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.7-4.2	16.2-21.0	070
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.9-4.6	19-30	All ES Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	3.9-4.9	18.3-25.9	All GS Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	4.0-4.6	19.0-30.0	All AU Models VT, HZ, CF, CS
GeoMaster, LLC	GeoExcel	GeoExcel	Open Loop	4.0-4.7	17.5-24.0	All GT Models VT, HZ, CF
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.5	16.1	All models beginning with YS070
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.5	17.3	All models beginning with YS036
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.6	17.9	All models beginning with YS060
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.6	18.1	All models beginning with YS048
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.7	18.5	All models beginning with YS042
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.8	17.5	All models beginning with YS024
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Closed Loop	3.8	18.3	All models beginning with YS030
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.0	21.0	All models beginning with YS070
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.0	23.0	All models beginning with YS060
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.2	23.4	All models beginning with YS048
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.3	23	All models beginning with YS036
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.3	23.5	All models beginning with YS042
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.4	23.9	All models beginning with YS030
GeoSmart Energy Inc.	GeoSmart Energy	Eco Y	Open Loop	4.5	23.4	All models beginning with YS024
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.3	15.2	All models beginning with ZS070****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.3	15.8	All models beginning with ZS041****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.3	16.6	All models beginning with ZS036****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.3	16.6	All models beginning with ZS060****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.3	16.8	All models beginning with ZS042****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.3	16.8	All models beginning with ZS048****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.4	16.5	All models beginning with ZS041****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.4	16.8	All models beginning with ZS023****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.5	16.1	All models beginning with ZS070****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.5	17.0	All models beginning with ZS018****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.5	17.0	All models beginning with ZS024****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.5	17.0	All models beginning with ZS030****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.5	17.2	All models beginning with ZS015****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.5	17.3	All models beginning with ZS036****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.6	17.0	All models beginning with ZS023****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.6	17.9	All models beginning with ZS060****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.6	18.1	All models beginning with ZS048****1

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.7	17.5	All models beginning with ZS015****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.7	17.5	All models beginning with ZS018****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.7	18.5	All models beginning with ZS042****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.8	17.5	All models beginning with ZS024****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Closed Loop	3.8	18.3	All models beginning with ZS030****1
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	3.7	18.2	All models beginning with ZS009****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	3.8	18.2	All models beginning with ZS012****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	3.8	21.0	All models beginning with ZS048****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	3.8	22.0	All models beginning with ZS042****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	3.9	21.2	All models beginning with ZS036****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	3.9	22.5	All models beginning with ZS023****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	4.0	22.8	All models beginning with ZS024****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	4.0	23.0	All models beginning with ZS030****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	4.0	23.5	All models beginning with ZS018****0
GeoSmart Energy Inc.	GeoSmart Energy	Eco Z	Open Loop	4.1	24.0	All models beginning with ZS015****0
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	3.7	17.9	All models beginning with GS070
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	3.8	19.2	All models beginning with GS060
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	3.9	21.2	All models beginning with GS030
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.0	19.5	All models beginning with GS048
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.0	19.9	All models beginning with GS072
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.0	21.8	All models beginning with GS064
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.0	22.0	All models beginning with GS022
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.1	22.2	All models beginning with GS042
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.2	21.8	All models beginning with GS036
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.4	21.5	All models beginning with GS049
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.4	22.7	All models beginning with GS026
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Closed Loop	4.4	25.0	All models beginning with GS038
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	4.5	23.2	All models beginning with GS072
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	4.5	24.3	All models beginning with GS070
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	4.6	25.5	All models beginning with GS060
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	4.7	26.0	All models beginning with GS064
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	4.9	27.0	All models beginning with GS048
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.0	25.5	All models beginning with GS049
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.1	29.5	All models beginning with GS042
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.1	30.0	All models beginning with GS030
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.2	27.6	All models beginning with GS026
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.2	28.1	All models beginning with GS038
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.2	29.8	All models beginning with GS036
GeoSmart Energy Inc.	GeoSmart Energy	PremiumG	Open Loop	5.4	32.2	All models beginning with GS022
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Closed Loop	3.4	15.1	All models beginning with QT064
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Closed Loop	3.6	14.7	All models beginning with QT072
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Closed Loop	3.6	16.3	All models beginning with QT049
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Closed Loop	3.9	18.2	All models beginning with QT038
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Open Loop	4.0	17.4	All models beginning with QT072
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Open Loop	4.0	18.5	All models beginning with QT064
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Open Loop	4.4	21.7	All models beginning with QT049
GeoSmart Energy Inc.	GeoSmart Energy	PremiumQ	Open Loop	4.5	19.3	All models beginning with QT038
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.3	14.6	Any Model Starting with GV36
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.4	14.1	Any Model Starting with GH18
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.4	14.1	Any Model Starting with GV18
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.4	15.1	Any Model Starting with GH23
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.4	15.2	Any Model Starting with GV23
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.5	14.5	Any Model Starting with GH29
GeoSystems, LLC	ECONAR	GeoSource 2000	Closed Loop	3.5	14.5	Any Model Starting with GV29
GeoSystems, LLC	ECONAR	GeoSource 2000	Open Loop	3.7	16.5	All Models Starting with GV36
GeoSystems, LLC	ECONAR	GeoSource 2000	Open Loop	3.9	17.2	All Models Starting with GH23
GeoSystems, LLC	ECONAR	GeoSource 2000	Open Loop	3.9	17.2	All Models Starting with GV23
GeoSystems, LLC	ECONAR	GeoSource DualTEK	Closed Loop	3.3	14.6	Any Model Starting with GV36
GeoSystems, LLC	ECONAR	GeoSource DualTEK	Open Loop	3.7	16.5	All Models Starting with GV36
GeoSystems, LLC	ECONAR	GeoSource Vara	Closed Loop	3.3	14.6	Any Model Starting with GV36
GeoSystems, LLC	ECONAR	GeoSource Vara	Open Loop	3.7	16.5	All Models Starting with GV36
GeoSystems, LLC	ECONAR	Invision3	Closed Loop	3.7	16.7	Any Model Starting with Q16kW5T
GeoSystems, LLC	ECONAR	Invision3	Closed Loop	3.85	17.2	Any Model Starting with Q14kW4T
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any models starting with GV47
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any models starting with GV57
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any models starting with GV77
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any model starting with GH17
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any model starting with GH37
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any model starting with GH47
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any model starting with GH57
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any model starting with GV17
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.3	14.1	Any model starting with GV37
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.4	15.2	Any model starting with GH27
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.4	15.2	Any model starting with GV27
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.65	16.0	Any model starting with GH110
GeoSystems, LLC	ECONAR	Ultra Forced Air	Closed Loop	3.7	14.1	Any model starting with GH87
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any models starting with GV47
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any models starting with GV77
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any model starting with GH17
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any model starting with GH47
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any model starting with GH57
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any model starting with GH87
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any model starting with GV17
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.2	Any model starting with GV37
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.3	Any model starting with GH37
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.6	16.6	Any models starting with GV57
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.7	16.4	Any model starting with GH27
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.7	16.4	Any model starting with GV27
GeoSystems, LLC	ECONAR	Ultra Forced Air	Open Loop	3.8	20.0	Any model starting with GH110
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.4	14.2	Any model starting with GH68
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.4	14.2	Any model starting with GH78
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.4	14.2	Any model starting with GV68
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.4	14.2	Any model starting with GV78
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.70	16.15	Any Model Starting with GH58
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.70	16.15	Any Model Starting with GV58
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.85	16.55	Any Model Starting with GH48

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	3.85	16.55	Any Model Starting with GV48
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	4.1	19.4	Any Model Starting with GH38
GeoSystems, LLC	ECONAR	Vara2Plus	Closed Loop	4.1	19.4	Any Model Starting with GV38
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	3.75	16.75	All Models Starting with GH58
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	3.75	16.75	All Models Starting with GV58
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	3.9	16.2	Any model starting with GH68
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	3.9	16.2	Any model starting with GV78
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	3.9	16.2	Any model starting with GV68
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	3.9	16.2	Any model starting with GV78
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	4.0	18.6	All Models Starting with GH48
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	4.0	18.6	All Models Starting with GV48
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	4.2	20.3	All Models Starting with GH38
GeoSystems, LLC	ECONAR	Vara2Plus	Open Loop	4.2	20.3	All Models Starting with GV38
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Closed Loop	3.3-3.6	14.1-15.0	HE1D 0265, 0365, 0465, 0545, 0685
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Closed Loop	3.3-3.6	14.1-15.0	HE1V 0265, 0365, 0465, 0545, 0685
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Closed Loop with integrated WH	3.3-3.6	14.1-15.0	HE1D 026W, 036W, 046W, 054W, 068W
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Closed Loop with integrated WH	3.3-3.6	14.1-15.0	HE1V 026W, 036W, 046W, 054W, 068W
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Open Loop	3.8-4.0	16.2-18.6	HE1D 0265, 0365, 0465, 0545, 0685
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Open Loop	3.8-4.0	16.2-18.6	HE1V 0265, 0365, 0465, 0545, 0685
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Open Loop with integrated WH	3.8-4.0	16.2-18.6	HE1D 026W, 036W, 046W, 054W, 068W
GeoSystems, LLC	HydroHeat	Extended Range (R22)	Open Loop with integrated WH	3.8-4.0	16.2-18.6	HE1V 026W, 036W, 046W, 054W, 068W
GeoSystems, LLC	HydroHeat	Extended Range (R410A)	Closed Loop	3.8	17.1-18.5	Any model beginning with HE2V or HE2D
GeoSystems, LLC	HydroHeat	Extended Range (R410A)	Closed Loop	3.3-3.4	14.7-15.5	Any model beginning with HE2V or HE2D
GeoSystems, LLC	HydroHeat	Horizon (R410A)	Closed Loop	3.3-3.4	14.4-15.2	HR2H 0165, 0215, 0285, 0335, 0395, 0475, 0575, 0695
GeoSystems, LLC	HydroHeat	Horizon (R410A)	Open Loop	3.6-4.0	17.4-17.9	HR2H 0165, 0215, 0285, 0335, 0395, 0475, 0575, 0695
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop	3.9-4.2	16.2-17.3	MT1D 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop	3.5-3.6	14.1	MT1D 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop	3.5-3.6	14.1	MT1V 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop	3.5-3.6	14.1	MT3D 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop	3.5-3.6	14.1	MT3V 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop with integrated WH	3.5-3.6	14.1	MT1D 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop with integrated WH	3.5-3.6	14.1	MT1V 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop with integrated WH	3.5-3.6	14.1	MT3D 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Closed Loop with integrated WH	3.5-3.6	14.1	MT3V 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop	3.9-4.2	16.2-17.3	MT1V 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop	3.9-4.2	16.2-17.3	MT3D 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop	3.9-4.2	16.2-17.3	MT3V 0405, 0555, 0625
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop with integrated WH	3.9-4.2	16.2-17.3	MT1D 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop with integrated WH	3.9-4.2	16.2-17.3	MT1V 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop with integrated WH	3.9-4.2	16.2-17.3	MT3D 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R22)	Open Loop with integrated WH	3.9-4.2	16.2-17.3	MT3V 040T, 055T, 062T
GeoSystems, LLC	HydroHeat	Mega-Tek (R410A)	Closed Loop	3.4-3.5	16.3-18.1	Any model beginning with MT4V or MT4D
GeoSystems, LLC	HydroHeat	Mega-Tek (R410A)	Open Loop	4.2	22.4-22.9	Any model beginning with MT4V or MT4D
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.3	14.4	HPH/HPV042 1
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.3	14.8	HPH/HPV060 1
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.3	14.9	HPH/HPV036 1
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.3	15.4	HPH/HPV024 1
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.4	14.7	HPH/HPV048 1
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.4	15.1	HPH/HPV030 1
Heat Controller Inc.	Heat Controller	Century	Closed Loop	3.4	16.3	HPH/HPV018 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	3.8	19.6	HPH/HPV042 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	3.9	19.9	HPH/HPV060 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	4.0	20.7	HPH/HPV036 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	4.1	20.1	HPH/HPV030 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	4.1	20.5	HPH/HPV048 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	4.1	20.9	HPH/HPV024 1
Heat Controller Inc.	Heat Controller	Century	Open Loop	4.4	24.2	HPH/HPV018 1
Heat Controller Inc.	Heat Controller		Closed Loop	3.3	14.3	HRV/HRH048B1
Heat Controller Inc.	Heat Controller		Closed Loop	3.3	15.9	HSS036
Heat Controller Inc.	Heat Controller		Closed Loop	3.4	14.4	HRV/HRH030B1
Heat Controller Inc.	Heat Controller		Closed Loop	3.4	14.7	HRV/HRH036B1
Heat Controller Inc.	Heat Controller		Closed Loop	3.4	15.0	HRV/HRH042B1
Heat Controller Inc.	Heat Controller		Closed Loop	3.4	15.0	HTD070 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.4	15.0	HTV070 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.5	14.2	HSS060
Heat Controller Inc.	Heat Controller		Closed Loop	3.5	16.2	HSS018
Heat Controller Inc.	Heat Controller		Closed Loop	3.5	16.4	HSS030
Heat Controller Inc.	Heat Controller		Closed Loop	3.5	16.6	HSS024
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	15.3	HTS060 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	15.5	HSS042
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	15.9	HSS048
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	16.2	HTD060 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	16.2	HTV060 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	19.8	HTD070 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.6	19.8	HTV070 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.7	16.6	HTD048 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.7	16.6	HTV048 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.7	16.9	HTD036 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.7	16.9	HTV036 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.7	17.1	HTD024 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.7	17.1	HTV024 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.8	16.7	HTS036 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	3.9	18.0	HTS024 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.0	16.6	HTS048 Full Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.0	22.2	HTS060 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.0	23.4	HTD060 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.1	23.7	HTS036 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.1	24.5	HTS024 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.2	22.8	HTS036 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.2	22.8	HTS048 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.2	23	HTV048 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.2	23.0	HTD048 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.2	25	HTV036 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.2	25.0	HTD036 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.3	24.1	HTD024 Part Load
Heat Controller Inc.	Heat Controller		Closed Loop	4.3	23.4	HTV060 Part Load

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
Heat Controller Inc.	Heat Controller		Closed Loop	4.3	24.1	HTV024 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	3.6	17.6	HRV/HRH019B1
Heat Controller Inc.	Heat Controller		Open Loop	3.6	17.6	HRV/HRH024B1
Heat Controller Inc.	Heat Controller		Open Loop	3.7	17.2	HSS060
Heat Controller Inc.	Heat Controller		Open Loop	3.8	16.8	HRV/HRH060B1
Heat Controller Inc.	Heat Controller		Open Loop	3.8	16.8	HRV/HRH070B1
Heat Controller Inc.	Heat Controller		Open Loop	3.8	18.1	HRV/HRH048B1
Heat Controller Inc.	Heat Controller		Open Loop	3.9	19.3	HSS048
Heat Controller Inc.	Heat Controller		Open Loop	3.9	19.7	HSS042
Heat Controller Inc.	Heat Controller		Open Loop	3.9	20.1	HSS036
Heat Controller Inc.	Heat Controller		Open Loop	3.9	20.6	HSS024
Heat Controller Inc.	Heat Controller		Open Loop	3.9	20.8	HSS030
Heat Controller Inc.	Heat Controller		Open Loop	3.9	18.2	HRV/HRH036B1
Heat Controller Inc.	Heat Controller		Open Loop	3.9	18.3	HRV/HRH030B1
Heat Controller Inc.	Heat Controller		Open Loop	3.9	18.6	HRV/HRH042B1
Heat Controller Inc.	Heat Controller		Open Loop	4.0	18.4	HTD070 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.0	18.4	HTV070 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.0	22.1	HSS018
Heat Controller Inc.	Heat Controller		Open Loop	4.0	22.7	HTD070 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.0	22.7	HTV070 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.1	20.3	HTD060 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.1	20.3	HTV060 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.3	19.2	HTS060 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.3	20.9	HTD048 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.3	20.9	HTV048 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.3	21.3	HTD036 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.3	21.3	HTV036 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.4	22.7	HTD024 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.4	22.7	HTV024 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.4	25.7	HTS060 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.4	27.5	HTD060 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.4	27.5	HTV060 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.5	21.4	HTS036 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.6	20.9	HTS048 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.6	27.1	HTS036 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.6	29.4	HTS024 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.7	23.2	HTS024 Full Load
Heat Controller Inc.	Heat Controller		Open Loop	4.7	26.5	HTD048 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.7	26.5	HTV048 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.7	26.8	HTS048 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.7	28.5	HTD024 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.7	28.5	HTV024 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.8	29.1	HTD036 Part Load
Heat Controller Inc.	Heat Controller		Open Loop	4.8	29.1	HTV036 Part Load
Maritime Geothermal Ltd.	Nordic	Nordic	Closed Loop	3.68-4.15	16.43-24.4	All models beginning with TF (H), 25-75
Maritime Geothermal Ltd.	Nordic	Nordic	Closed Loop	3.69-4.28	16.6-24.4	All models beginning with R, RS, or RH, 25-75
Maritime Geothermal Ltd.	Nordic	Nordic	DGX	3.82-4.28	20.9-23.8	All models beginning with DX (S), 25-65
Maritime Geothermal Ltd.	Nordic	Nordic	DGX	3.82-4.28	20.9-23.8	All models beginning with DXTF (S), 25-65
Maritime Geothermal Ltd.	Nordic	Nordic	Open Loop	4.09-4.72	18.69-30.96	All models beginning with TF (H), 25-75
Maritime Geothermal Ltd.	Nordic	Nordic	Open Loop	4.26-4.79	19.15-30.96	All models beginning with R, RS, or RH, 25-75
Northern Heat Pump Ltd.	Northern Heat Pump	Serenity	Closed Loop	3.6	16.6	RT-VE-033
Northern Heat Pump Ltd.	Northern Heat Pump	Serenity	Closed Loop	3.7	16.7	RT-VE-062
Northern Heat Pump Ltd.	Northern Heat Pump	Serenity	Closed Loop	3.7	18.2	RT-VE-045
Northern Heat Pump Ltd.	Northern Heat Pump	Serenity	Closed Loop	3.8	17.9	RT-VE-040
Northern Heat Pump Ltd.	Northern Heat Pump	Serenity	Closed Loop	3.8	18.6	RT-VE-052
Northern Heat Pump Ltd.	Northern Heat Pump	Serenity	Closed Loop	3.8	18.8	RT-VE-073
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.3	12.2	RTVE60
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.3	16.5	RTHE51 (P)
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.3	16.5	RTVE51 (P)
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.3	23	RTHE30 (P)
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.3	23	RTVE30 (P)
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.4	17.7	RTHE60 (P)
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.4	17.7	RTVE60 (P)
Northern Heat Pump Ltd.	Northern Heat Pump	XTERRA	Closed Loop	3.6	20.6	RTVE40 (P)
Rheem Manufacturing Company	Rheem	Prestige	Closed Loop	3.6-4.2	18.4-22.4	All models beginning with RPV
Rheem Manufacturing Company	Rheem	Prestige	Open Loop	3.95-4.85	22-27.45	All models beginning with RPV
Rheem Manufacturing Company	Ruud	Ultra	Closed Loop	3.6-4.2	18.4-22.4	All models beginning with RPV
Rheem Manufacturing Company	Ruud	Ultra	Open Loop	3.95-4.85	22-27.45	All models beginning with RPV
Sub Terra Energy Systems	Sub Terra		DGX	4.54	15.5	STESH410
Sub Terra Energy Systems	Sub Terra		DGX	4.6	15.7	STE3H410
Sub Terra Energy Systems	Sub Terra		DGX	4.6	15.7	STE4H22
Sub Terra Energy Systems	Sub Terra		DGX	4.6	15.7	STE4H410
Sub Terra Energy Systems	Sub Terra		DGX	4.66	15.9	STESH22
WaterFurnace International, Incorporated	WaterFurnace	US(V/H)048****1	Closed Loop	3.6	18.1	Any model starting with US(V/H)048****1
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.3	15.2	Any model starting with LS(V/H)070*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.3	16.6	Any model starting with LS(V/H)036*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.3	16.6	Any model starting with LS(V/H)060*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.3	16.8	Any model starting with LS(V/H)042*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.3	16.8	Any model starting with LS(V/H)048*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.5	16.1	Any model starting with LS(V/H)070*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.5	17.0	Any model starting with LS(V/H)024*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.5	17.0	Any model starting with LS(V/H)030*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.5	17.3	Any model starting with LS(V/H)036*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.6	17.9	Any model starting with LS(V/H)060*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.6	18.1	Any model starting with LS(V/H)048*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.7	18.5	Any model starting with LS(V/H)042*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.8	17.5	Any model starting with LS(V/H)024*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Closed Loop	3.8	18.3	Any model starting with LS(V/H)030*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	3.8	20.3	Any model starting with LS(V/H)070*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	3.8	20.8	Any model starting with LS(V/H)060*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	3.8	21.0	Any model starting with LS(V/H)048*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	3.8	22.0	Any model starting with LS(V/H)042*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	3.9	21.2	Any model starting with LS(V/H)036*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	4.0	21.0	Any model starting with LS(V/H)070*1*4
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	4.0	22.8	Any model starting with LS(V/H)024*1*0
WaterFurnace International, Incorporated	WaterFurnace	Legend	Open Loop	4.0	23.0	Any model starting with LS(V/H)030*1*0

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
Watermaster Geothermal	Watermaster	Ultra Performance	Closed Loop	3.7	19.1	WMO301VOO
Watermaster Geothermal	Watermaster	Ultra Performance	Closed Loop	4.3	22.3	WMO601VHG
WFI Industries	GeoStar		Closed Loop	3.3	15.1	Any model starting with GS2070
WFI Industries	GeoStar		Closed Loop	3.4	15.1	Any model starting with QT064
WFI Industries	GeoStar		Closed Loop	3.4	16.7	Any model starting with GS009
WFI Industries	GeoStar		Closed Loop	3.4	17.2	Any model starting with GS070****0
WFI Industries	GeoStar		Closed Loop	3.6	14.7	Any model starting with QT072
WFI Industries	GeoStar		Closed Loop	3.6	16.3	Any model starting with QT049
WFI Industries	GeoStar		Closed Loop	3.6	17.0	Any model starting with GS2060
WFI Industries	GeoStar		Closed Loop	3.6	17.0	Any model starting with GT2072
WFI Industries	GeoStar		Closed Loop	3.6	17.3	Any model starting with GS048****0
WFI Industries	GeoStar		Closed Loop	3.6	18.0	Any model starting with GS012
WFI Industries	GeoStar		Closed Loop	3.6	18.0	Any model starting with GS018****0
WFI Industries	GeoStar		Closed Loop	3.7	18.0	Any model starting with GS015****0
WFI Industries	GeoStar		Closed Loop	3.7	18.2	Any model starting with GS070****1
WFI Industries	GeoStar		Closed Loop	3.7	18.5	Any model starting with GS060****0
WFI Industries	GeoStar		Closed Loop	3.7	18.6	Any model starting with GS042****0
WFI Industries	GeoStar		Closed Loop	3.7	18.8	Any model starting with GT2064
WFI Industries	GeoStar		Closed Loop	3.7	19.5	Any model starting with GS2022
WFI Industries	GeoStar		Closed Loop	3.7	19.9	Any model starting with GS2042
WFI Industries	GeoStar		Closed Loop	3.8	18.1	Any model starting with GS2048
WFI Industries	GeoStar		Closed Loop	3.8	18.5	Any model starting with GS015****1
WFI Industries	GeoStar		Closed Loop	3.8	20.3	Any model starting with GS022****0
WFI Industries	GeoStar		Closed Loop	3.8	21.1	Any model starting with GS030****0
WFI Industries	GeoStar		Closed Loop	3.9	18.2	Any model starting with QT038
WFI Industries	GeoStar		Closed Loop	3.9	19.0	Any model starting with GS018****1
WFI Industries	GeoStar		Closed Loop	3.9	19.5	Any model starting with GS060****1
WFI Industries	GeoStar		Closed Loop	4.0	19.5	Any model starting with GTZ049
WFI Industries	GeoStar		Closed Loop	4.0	19.6	Any model starting with GS036****0
WFI Industries	GeoStar		Closed Loop	4.0	19.7	Any model starting with GS048****1
WFI Industries	GeoStar		Closed Loop	4.0	19.8	Any model starting with GS2030
WFI Industries	GeoStar		Closed Loop	4.0	19.8	Any model starting with GS2036
WFI Industries	GeoStar		Closed Loop	4.0	19.9	Any model starting with GT072
WFI Industries	GeoStar		Closed Loop	4.0	21.0	Any model starting with GS022****1
WFI Industries	GeoStar		Closed Loop	4.0	21.2	Any model starting with GTZ038
WFI Industries	GeoStar		Closed Loop	4.0	21.8	Any model starting with GT064
WFI Industries	GeoStar		Closed Loop	4.0	21.9	Any model starting with GS030****1
WFI Industries	GeoStar		Closed Loop	4.1	20.7	Any model starting with GT2026
WFI Industries	GeoStar		Closed Loop	4.2	21.4	Any model starting with GS042****1
WFI Industries	GeoStar		Closed Loop	4.4	21.5	Any model starting with GT049
WFI Industries	GeoStar		Closed Loop	4.4	22.0	Any model starting with GS036****1
WFI Industries	GeoStar		Closed Loop	4.4	22.7	Any model starting with GT026
WFI Industries	GeoStar		Closed Loop	4.4	25.0	Any model starting with GT038
WFI Industries	GeoStar		Open Loop	3.7	19.2	Any model starting with GS2070
WFI Industries	GeoStar		Open Loop	3.9	20.3	Any model starting with GT2072
WFI Industries	GeoStar		Open Loop	4.0	17.4	Any model starting with QT072
WFI Industries	GeoStar		Open Loop	4.0	18.5	Any model starting with QT064
WFI Industries	GeoStar		Open Loop	4.0	21.6	Any model starting with GS070****0
WFI Industries	GeoStar		Open Loop	4.1	21.1	Any model starting with GS2060
WFI Industries	GeoStar		Open Loop	4.2	25.5	Any model starting with GS012
WFI Industries	GeoStar		Open Loop	4.3	22.0	Any model starting with GT2064
WFI Industries	GeoStar		Open Loop	4.3	22.2	Any model starting with GS009
WFI Industries	GeoStar		Open Loop	4.3	22.5	Any model starting with GS048****0
WFI Industries	GeoStar		Open Loop	4.4	21.7	Any model starting with QT049
WFI Industries	GeoStar		Open Loop	4.4	23.7	Any model starting with GTZ038
WFI Industries	GeoStar		Open Loop	4.4	23.8	Any model starting with GS070****1
WFI Industries	GeoStar		Open Loop	4.4	24.6	Any model starting with GS060****0
WFI Industries	GeoStar		Open Loop	4.4	25.5	Any model starting with GS018****0
WFI Industries	GeoStar		Open Loop	4.4	26.0	Any model starting with GS015****0
WFI Industries	GeoStar		Open Loop	4.5	19.3	Any model starting with QT038
WFI Industries	GeoStar		Open Loop	4.5	23.0	Any model starting with GTZ049
WFI Industries	GeoStar		Open Loop	4.5	23.2	Any model starting with GT072
WFI Industries	GeoStar		Open Loop	4.5	23.8	Any model starting with GS2048
WFI Industries	GeoStar		Open Loop	4.5	25.3	Any model starting with GS2042
WFI Industries	GeoStar		Open Loop	4.5	27.9	Any model starting with GS2022
WFI Industries	GeoStar		Open Loop	4.6	24.5	Any model starting with GS042****0
WFI Industries	GeoStar		Open Loop	4.7	25.1	Any model starting with GT2026
WFI Industries	GeoStar		Open Loop	4.7	25.7	Any model starting with GS036****0
WFI Industries	GeoStar		Open Loop	4.7	26.0	Any model starting with GT064
WFI Industries	GeoStar		Open Loop	4.7	26.1	Any model starting with GS060****1
WFI Industries	GeoStar		Open Loop	4.7	26.3	Any model starting with GS015****1
WFI Industries	GeoStar		Open Loop	4.7	26.3	Any model starting with GS018****1
WFI Industries	GeoStar		Open Loop	4.7	27.0	Any model starting with GS2036
WFI Industries	GeoStar		Open Loop	4.8	26.1	Any model starting with GS048****1
WFI Industries	GeoStar		Open Loop	4.8	27.1	Any model starting with GS030****0
WFI Industries	GeoStar		Open Loop	4.9	24.9	Any model starting with GS2030
WFI Industries	GeoStar		Open Loop	5.0	25.5	Any model starting with GT049
WFI Industries	GeoStar		Open Loop	5.0	28.0	Any model starting with GS022****0
WFI Industries	GeoStar		Open Loop	5.0	28.8	Any model starting with GS030****1
WFI Industries	GeoStar		Open Loop	5.2	27.6	Any model starting with GT026
WFI Industries	GeoStar		Open Loop	5.2	28.1	Any model starting with GT038
WFI Industries	GeoStar		Open Loop	5.2	29.5	Any model starting with GS042****1
WFI Industries	GeoStar		Open Loop	5.2	30.1	Any model starting with GS036****1
WFI Industries	GeoStar		Open Loop	5.3	30.0	Any model starting with GS022****1
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	15.2	Any model starting with YS070****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	15.2	Any model starting with ZS070****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	15.8	Any model starting with ZS041****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.6	Any model starting with YS036****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.6	Any model starting with YS060****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.6	Any model starting with ZS036****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.6	Any model starting with ZS060****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.8	Any model starting with YS042****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.8	Any model starting with YS048****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.8	Any model starting with ZS042****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.3	16.8	Any model starting with ZS048****0
WFI Industries	WFI Industries	GeoStar	Closed Loop	3.4	16.5	Any model starting with ZS041****1

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
Eagle Mountain	Eagle Mountain	GeoMax Cascade Series	Open Loop Water to Water	3.7	21.6	Any model starting with GSW050
Eagle Mountain	Eagle Mountain	GeoMax Cascade Series	Open Loop Water to Water	3.8	20.6	Any model starting with GSW060
Eagle Mountain	Eagle Mountain	GeoMax Cascade Series	Open Loop Water to Water	3.6	24.2	Any model starting with GTW100
Eagle Mountain	Eagle Mountain	GeoMax Cascade Series	Open Loop Water to Water	3.5	23.0	Any model starting with GTW120
Enertech Manufacturing LLC	GeoComfort	GWSR 1-Stage Water-to-Water	Closed Loop Water to Water	3.4	20.6	GWSR 036
Enertech Manufacturing LLC	GeoComfort	GWSR 1-Stage Water-to-Water	Closed Loop Water to Water	3.5	17.2	GWSR 060
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	19.0	GWT 026
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	19.3	GWT 034
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	18.8	GWT 046
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	18.2	GWT 058
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	16.7	GWT 070
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	18.8	GWT 092
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.5	17.2	GWT 120
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	19.0	RWT 026
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	19.3	RWT 034
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	18.8	RWT 046
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	18.2	RWT 058
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	16.7	RWT 070
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	18.8	RWT 092
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.5	17.2	RWT 120
Enertech Manufacturing LLC	TETCO	TWS 1-Stage Water-to-Water	Closed Loop Water to Water	3.4	20.6	TWS 036
Enertech Manufacturing LLC	TETCO	TWS 1-Stage Water-to-Water	Closed Loop Water to Water	3.5	17.2	TWS 060
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	19.0	TWT 026
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	19.3	TWT 034
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	18.8	TWT 046
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.2	18.2	TWT 058
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	16.7	TWT 070
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.1	18.8	TWT 092
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Closed Loop Water to Water	3.5	17.2	TWT 120
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.4	20.6	W 036
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.5	17.2	W 060
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.2	19.0	HWT 026
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.2	19.3	HWT 034
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.1	18.8	HWT 046
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.2	18.2	HWT 058
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.1	16.7	HWT 070
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.1	18.8	HWT 092
Enertech Manufacturing LLC	Hydron Module	Water	Closed Loop Water to Water	3.5	17.2	HWT 120
Enertech Manufacturing LLC	GeoComfort	GWSR 1-Stage Water-to-Water	Open Loop Water to Water	4.0	22.5	GWSR 036
Enertech Manufacturing LLC	GeoComfort	GWSR 1-Stage Water-to-Water	Open Loop Water to Water	4.0	21.7	GWSR 060
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	3.6	22.2	GWT 026
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	3.8	22.3	GWT 034
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	3.4	22.2	GWT 046
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	3.7	21.4	GWT 058
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	3.6	19.7	GWT 070
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	3.4	22.2	GWT 092
Enertech Manufacturing LLC	GeoComfort	GWT 2-Stage Water-to-Water	Open Loop Water to Water	4.0	21.7	GWT 120
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	3.6	22.2	RWT 026
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	3.8	22.3	RWT 034
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	3.4	22.2	RWT 046
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	3.7	21.4	RWT 058
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	3.6	19.7	RWT 070
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	3.4	22.2	RWT 092
Enertech Manufacturing LLC	Roth	RWT 2-Stage Water-to-Water	Open Loop Water to Water	4.0	21.7	RWT 120
Enertech Manufacturing LLC	TETCO	TWS 1-Stage Water-to-Water	Open Loop Water to Water	4.0	22.5	TWS 036
Enertech Manufacturing LLC	TETCO	TWS 1-Stage Water-to-Water	Open Loop Water to Water	4.0	21.7	TWS 060
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	3.6	22.2	TWT 026
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	3.8	22.3	TWT 034
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	3.4	22.2	TWT 046
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	3.7	21.4	TWT 058
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	3.6	19.7	TWT 070
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	3.4	22.2	TWT 092
Enertech Manufacturing LLC	TETCO	TWT 2-Stage Water-to-Water	Open Loop Water to Water	4.0	21.7	TWT 120
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	4.0	22.5	W 036
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	4.0	21.7	W 060
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	3.6	22.2	HWT 026
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	3.8	22.3	HWT 034
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	3.4	22.2	HWT 046
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	3.7	21.4	HWT 058
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	3.6	19.7	HWT 070
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	3.4	22.2	HWT 092
Enertech Manufacturing LLC	Hydron Module	Water	Open Loop Water to Water	4.0	21.7	HWT 120
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Closed Loop Water to Water	3.1	19.0	WT025
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Closed Loop Water to Water	3.0	17.6	WT035
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Closed Loop Water to Water	3.1	17.5	WT049
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Closed Loop Water to Water	3.2	17.3	WT061
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Closed Loop Water to Water	3.1	16.8	WT071
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Open Loop Water to Water	3.6	23.5	WT025
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Open Loop Water to Water	3.6	22.5	WT035
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Open Loop Water to Water	3.6	21.7	WT049
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Open Loop Water to Water	3.6	21.6	WT061
FHP Manufacturing Bosch Group	Aquarius Premier Water-to-Water	WT	Open Loop Water to Water	3.5	20.3	WT071
Geofinity Manufacturing	Tangaroa	TG036	Closed Loop Water to Water	3.2	16.0	TG036W/*S* - ****
Geofinity Manufacturing	Tangaroa	TG048	Closed Loop Water to Water	3.0	15.7	TG048W/*S* - ****
Geofinity Manufacturing	Tangaroa	TG060	Closed Loop Water to Water	3.1	17.1	TG060W/*S* - ****
Geofinity Manufacturing	Triakus	TK036	Closed Loop Water to Water	3.3	N/A	TK036W/*S* - ****
Geofinity Manufacturing	Triakus	TK048	Closed Loop Water to Water	3.0	NA	TK048W/*S* - ****
Geofinity Manufacturing	Triakus	TK060	Closed Loop Water to Water	3.1	NA	TK060W/*S* - ****
Geofinity Manufacturing	Tangaroa	TG036	Open Loop Water to Water	3.8	21.8	TG036W/*S* - ****
Geofinity Manufacturing	Tangaroa	TG048	Open Loop Water to Water	3.6	21.4	TG048W/*S* - ****
Geofinity Manufacturing	Tangaroa	TG060	Open Loop Water to Water	3.8	19.7	TG060W/*S* - ****
Geofinity Manufacturing	Triakus	TK036	Open Loop Water to Water	3.9	N/A	TK036W/*S* - ****
Geofinity Manufacturing	Triakus	TK048	Open Loop Water to Water	3.6	NA	TK048W/*S* - ****
Geofinity Manufacturing	Triakus	TK060	Open Loop Water to Water	3.9	NA	TK060W/*S* - ****
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	3.6	15.2	MW024S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	4.1	18.0	MW024T

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	3.8	15.6	MW036S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	4.3	18.7	MW036T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	3.7	15.3	MW048S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	4.2	18.6	MW048T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	3.7	15.2	MW060S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	4.2	18.4	MW060T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	3.5	15.2	MW072S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Closed Loop Water to Water	4.1	17.9	MW072T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	3.8	19.1	MW024S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.5	21.0	MW024T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.0	19.2	MW036S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.7	20.7	MW036T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.2	19.4	MW048S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.8	20.6	MW048T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.2	19.3	MW060S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.8	20.4	MW060T
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	3.9	19.3	MW072S
GeoFurnace Manufacturing, Inc	GeoFurnace	H20	Open Loop Water to Water	4.5	19.9	MW072T
GeoMaster, LLC		WT	Closed Loop Water to Water	3.1	19.0	WT025
GeoMaster, LLC		WT	Closed Loop Water to Water	3.0	17.6	WT035
GeoMaster, LLC		WT	Closed Loop Water to Water	3.1	17.5	WT049
GeoMaster, LLC		WT	Closed Loop Water to Water	3.2	17.3	WT061
GeoMaster, LLC		WT	Closed Loop Water to Water	3.1	16.8	WT071
GeoMaster, LLC		WT	Open Loop Water to Water	3.6	23.5	WT025
GeoMaster, LLC		WT	Open Loop Water to Water	3.6	22.5	WT035
GeoMaster, LLC		WT	Open Loop Water to Water	3.6	21.7	WT049
GeoMaster, LLC		WT	Open Loop Water to Water	3.6	21.6	WT061
GeoMaster, LLC		WT	Open Loop Water to Water	3.5	20.3	WT071
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.0	16.6	All models beginning with HS018
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.0	15.8	All models beginning with HS025
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.1	17.5	All models beginning with HS040
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.1	16.4	All models beginning with HS050
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.0	15.7	All models beginning with HS060
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.3	19.8	All models beginning with HT100
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.2	19.0	All models beginning with HT120
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.0	18.3	All models beginning with HT150
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Closed Loop Water-to-Water	3.1	17.1	All models beginning with HT180
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.7	22.9	All models beginning with HS018
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.8	21.2	All models beginning with HS025
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.9	23.4	All models beginning with HS040
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.7	21.6	All models beginning with HS050
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.8	20.6	All models beginning with HS060
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.6	24.2	All models beginning with HT100
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.5	23.0	All models beginning with HT120
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.4	21.0	All models beginning with HT150
GeoSmart Energy Inc.	GeoSmart Energy	PremiumH	Open Loop Water-to-Water	3.4	20.3	All models beginning with HT180
GeoSystems, LLC	HydroHeat	Magnum	Closed Loop Water to Water	3.0	15.2	Any model beginning with MG039
GeoSystems, LLC	HydroHeat	Magnum	Closed Loop Water to Water	3.0	15.1	Any model beginning with MG049
GeoSystems, LLC	HydroHeat	Magnum	Closed Loop Water to Water	3.0	15.1	Any model beginning with MG069
GeoSystems, LLC	ECONAR	Ultra Hydronic	Closed Loop Water to Water	3.9	15.4	Any model starting with GW110
GeoSystems, LLC	ECONAR	Ultra Hydronic	Closed Loop Water to Water	3.0	16.1	Any model starting with GW37
GeoSystems, LLC	ECONAR	Ultra Hydronic	Closed Loop Water to Water	3.0	16.8	Any model starting with GW47
GeoSystems, LLC	ECONAR	Ultra Hydronic	Closed Loop Water to Water	3.0	16.3	Any model starting with GW57
GeoSystems, LLC	ECONAR	Ultra Hydronic	Closed Loop Water to Water	3.0	17.0	Any model starting with GW77
GeoSystems, LLC	ECONAR	Ultra Hydronic	Closed Loop Water to Water	3.2	15.5	Any model starting with GW87
GeoSystems, LLC	HydroHeat	Magnum	Open Loop Water to Water	3.4	19.2	Any model beginning with MG039
GeoSystems, LLC	HydroHeat	Magnum	Open Loop Water to Water	3.4	19.4	Any model beginning with MG049
GeoSystems, LLC	HydroHeat	Magnum	Open Loop Water to Water	3.4	19.1	Any model beginning with MG069
GeoSystems, LLC	ECONAR	Ultra Hydronic	Open Loop Water to Water	3.6	19.2	Any model starting with GW110
GeoSystems, LLC	ECONAR	Ultra Hydronic	Open Loop Water to Water	3.4	21.5	Any model starting with GW37
GeoSystems, LLC	ECONAR	Ultra Hydronic	Open Loop Water to Water	3.5	21.9	Any model starting with GW47
GeoSystems, LLC	ECONAR	Ultra Hydronic	Open Loop Water to Water	3.5	20.4	Any model starting with GW57
GeoSystems, LLC	ECONAR	Ultra Hydronic	Open Loop Water to Water	3.7	22.5	Any model starting with GW77
GeoSystems, LLC	ECONAR	Ultra Hydronic	Open Loop Water to Water	3.6	19.5	Any model starting with GW87
Heat Controller Inc.	Comfort-Aire	Series	Closed Loop Water to Water	3.0	16.4	HW036A
Heat Controller Inc.	Comfort-Aire	Series	Closed Loop Water to Water	3.0	16.2	HW060A
Heat Controller Inc.	Comfort-Aire	Series	Closed Loop Water to Water	3.0	16.0	HW120A
Heat Controller Inc.	Comfort-Aire	Series	Open Loop Water to Water	4.0	23.1	HW036A
Heat Controller Inc.	Comfort-Aire	Series	Open Loop Water to Water	4.0	22.0	HW060A
Heat Controller Inc.	Comfort-Aire	Series	Open Loop Water to Water	3.9	21.6	HW120A
Maritime Geothermal Ltd.	Nordic	W25HACW	Closed Loop Water to Water	3.1	18.7	All Models beginning With W or (EMW)25HACW
Maritime Geothermal Ltd.	Nordic	W45HACW	Closed Loop Water to Water	3.2	18.4	All Models beginning With W or (EMW)45HACW
Maritime Geothermal Ltd.	Nordic	W55HACW	Closed Loop Water to Water	3.2	17.3	All Models beginning With W or (EMW)55HACW
Maritime Geothermal Ltd.	Nordic	W65HACW	Closed Loop Water to Water	3.2	17.8	All Models beginning With W or (EMW)65HACW
Maritime Geothermal Ltd.	Nordic	W75HACW	Closed Loop Water to Water	3.2	16.7	All Models beginning With W or (EMW)75HACW
Maritime Geothermal Ltd.	Nordic	W25HACW	Open Loop Water to Water	3.8	23.7	All Models beginning With W or (EMW)25HACW
Maritime Geothermal Ltd.	Nordic	W45HACW	Open Loop Water to Water	3.9	22.9	All Models beginning With W or (EMW)45HACW
Maritime Geothermal Ltd.	Nordic	W55HACW	Open Loop Water to Water	3.8	22.0	All Models beginning With W or (EMW)55HACW
Maritime Geothermal Ltd.	Nordic	W65HACW	Open Loop Water to Water	3.8	22.2	All Models beginning With W or (EMW)65HACW
Maritime Geothermal Ltd.	Nordic	W75HACW	Open Loop Water to Water	4.0	20.6	All Models beginning With W or (EMW)75HACW
Northern Heat Pump, Ltd.	Northern Heat Pump	Serenity	Closed Loop Water to Water	3.8	16.8	RA-WE-036
Northern Heat Pump, Ltd.	Northern Heat Pump	Serenity	Closed Loop Water to Water	3.4	16.5	RA-WE-050
Northern Heat Pump, Ltd.	Northern Heat Pump	Serenity	Closed Loop Water to Water	3.7	15.4	RA-WE-057
Northern Heat Pump, Ltd.	Northern Heat Pump	Serenity	Closed Loop Water to Water	3.6	15.2	RA-WE-070
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	EW Series	Closed Loop Water to Water	3.0	15.2	Any model starting with EW020
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	EW Series	Closed Loop Water to Water	3.0	16.5	Any model starting with EW030
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	EW Series	Closed Loop Water to Water	3.0	15.4	Any model starting with EW042
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.3	19.8	Any model starting with NDW100
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.6	24.2	Any model starting with NDW100
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.2	19.0	Any model starting with NDW120
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.0	16.6	Any model starting with NSW018
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.0	15.8	Any model starting with NSW025
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.1	17.5	Any model starting with NSW040
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.1	16.4	Any model starting with NSW050
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Closed Loop Water to Water	3.0	15.7	Any model starting with NSW060
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	EW Series	Open Loop Water to Water	3.4	19.1	Any model starting with EW020

Florida ENERGY STAR HVAC Rebate Program
Geothermal Units Brand/Model Number Listing

Manufacturer Name	Brand Name	Model Name	Product Type	COP Rating	EER Rating	Model Number
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	EW Series	Open Loop Water to Water	3.4	19.1	Any model starting with EW030
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	EW Series	Open Loop Water to Water	3.4	19.1	Any model starting with EW042
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Open Loop Water to Water	3.5	23.0	Any model starting with NDW120
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Open Loop Water to Water	3.7	22.9	Any model starting with NSW018
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Open Loop Water to Water	3.8	21.2	Any model starting with NSW025
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Open Loop Water to Water	3.9	23.4	Any model starting with NSW040
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Open Loop Water to Water	3.7	21.6	Any model starting with NSW050
WaterFurnace International, Incorporated	WaterFurnace International, Inc.	Envision	Open Loop Water to Water	3.8	20.6	Any model starting with NSW060
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.0	16.6	Any model starting with GSW018
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.0	15.8	Any model starting with GSW025
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.1	17.5	Any model starting with GSW040
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.1	16.4	Any model starting with GSW050
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.0	15.7	Any model starting with GSW060
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.3	19.8	Any model starting with GTW100
WFI Industries	WFI Industries	Geo Star	Closed Loop Water to Water	3.2	19.0	Any model starting with GTW120
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.7	22.9	Any model starting with GSW018
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.8	21.2	Any model starting with GSW025
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.9	23.4	Any model starting with GSW040
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.7	21.6	Any model starting with GSW050
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.8	20.6	Any model starting with GSW060
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.6	24.2	Any model starting with GTW100
WFI Industries	WFI Industries	Geo Star	Open Loop Water to Water	3.5	23.0	Any model starting with GTW120